

Step by step manual – Black&White4 CTM plus



A ▶ Preparation

Fold out the milk lance (1). Operate the milk lance using the hand gear only. Place milk lance in milk packaging (shake well beforehand) or pitcher (2) with alternative type of milk.



B ▶ The right cup

Place the cup (3) under the product outlet.



C ▶ Alternative milk

Select product group «Milk Plus» (4) on the product screen.



D ▶ Beverage selection

Select the desired product (5), the product is dispensed.



E ▶ Almost ready

Remove the milk packaging/pitcher from the milk lance and refrigerate the remaining milk.



F ▶ Pure indulgence

The drink is ready.



G ▶ Milk lance cleaning and contamination rinse

For cleaning the outside of the milk lance, a separate, clean cloth must be used for each type of milk.

- Clean the entire outside of the milk lance (6).
- Make sure that there is no backlog left.
- Press rinse milk path (7). Milk lance is rinsed.
- Clean the pitcher (if used) thoroughly with warm water and detergent.

The machine is ready for the next type of milk!